



# NEX STAR<sup>®</sup>

TRAINING SYSTEM



## ASSEMBLY MANUAL



Congratulations on your purchase of the NexStar Training System. The following is a list of all components included in the NexStar System.

### PARTS LIST:

1. Nylon carry bag
2. Tripod (a) with platform (b)
3. NexStar frame for your iPad (c)
4. Action handle (d)
5. Base unit (e)
6. Stability spikes (f)
7. Wedges (g)




### SET UP:

Remove the tripod (a) from the carry bag. Extend each of the three legs by releasing the tabs on each leg. Extend the legs to a comfortable height for each individual user. Once the tripod is set up, remove the DSLR platform (b) located at the top of the tripod head by pulling the small lever out to release the platform. Keep the platform for use with your DSLR camera.




### FRAME ATTACHMENT:

Remove frame (c) from bag and attach the frame to the area vacated by the platform (b). Lock frame in place with the locking lever on top of tripod head.




### INSERT IPAD:

Remove two wedges (g) from top of frame by loosening thumb screws and pulling wedges toward the user. Insert iPad by resting the bottom of iPad into the frame being sure to set inside the tabs at the bottom of frame. Tilt iPad forward until fully inserted within the frame. Replace two wedges (g) by inserting into slots in frame and re-tighten. Hint: Make sure frame is tilted away from you when inserting iPad until wedges are replaced.



### ACTION HANDLE: (d)

For times when more mobility is needed, the action handle gives complete range of motion without the tripod. Insert the frame into the action handle until it "clicks" into place. To remove the frame from the handle, depress the clip with thumb while pulling frame towards user. Full mobility.




### BASE UNIT: (e)

With the frame inserted into the action handle, push handle end deep into the base unit (e) for desk top reviewing. Can also be used in this setup for recording actions near ground level eg. putting stroke, bowling approach, etc.



### GROUND LOCK SYSTEM: (f)

Under windy conditions the NexStar System can be securely locked to the ground using the NexStar stability spikes (f) inserted through the legs and into the ground.



### ORIENTATION MODES:

Loosen tripod head to rotate platform to the left to shoot in Portrait mode. Re-tighten platform head adjustment. Use horizontal level to adjust.



### WARRANTY

Please visit our web site  
for full warranty details.  
[www.nexstartraining.com](http://www.nexstartraining.com)



Visit our web site also for updates  
from users sharing their experiences  
with the many ways the NexStar  
System can be used.

Scan QR for assembly video or go to  
[nexstartraining.com/setup](http://nexstartraining.com/setup)